



CONTENTS SUPPLIED

- (a.) Frame
- (b.) Canopy Top
- (c.) Carry Bag




HARDWARE HIGHLIGHTS

- (a.) Peak Tensioning Device
(DO NOT crank-up until fabric is stretched)
- (b.) Velcro Sewn Inside
- (c.) Easy Release Thumb Latch




*DO NOT crank up unless fabric is stretched.

*Used For Backwall Attachment




*Easy To Use Thumb Latch.



CANOPY


Assembly Instructions

STEP 1




Start with the frame standing upright.

STEP 2



Grab one leg of the frame with each hand and lift up and out to extend the frame until it is near halfway open.

STEP 3




***MUST DO**
CORNER OF FRAME

0.75in
Stitch Line
VELCRO on Canopy Frame
VELCRO on Canopy Top

Place top corner stitch line low enough so there is 0.75in from stitch line to the top of frame corner. This will ensure ideal peak tension.

Place the canopy top over the frame. Go to each corner and attach the velcro inside the canopy top to the velcro on the top edge of the canopy frame.


STEP 4



WARNING! Do not place hands above or below corner leg latch

Grab the center cross bars with both hands and lift up until the frame is fully extended.


STEP 5



CORRECT VERSION
Place hand on side bar that connects to latch

With one hand holding the frame leg, reach under the canopy top with the other hand, and push up until you feel it click into place. Do this on all four corners.

STEP 6



Rotate the Peak Tensioning Device handle only when the Fabric is stretched.

Go to each leg, place your foot on the canopy footpad, grab the leg and lift up to raise the canopy. Do this on all four corners until desired height is reached. Use the Peak Tensioning Device to raise canopy top.

***PLEASE BE SURE TO STAKE DOWN OR WEIGH DOWN CANOPY TO PREVENT LIABILITY**